PRÓCHEM

Product Specification Sheet

S778 HEAT WAVE

LABEL INSTRUCTIONS

Product Description & Directions For Use:

A highly concentrated carpet cleaning detergent, specially formulated for use in high heat truck mount and portable extraction cleaning equipment. Heat Wave dissolves quickly to give a powerful crystal clear solution that is stable at high cleaning temperatures. With a fresh tropical lemon fragrance, Heat Wave breaks through heavy soil and grease then rinses out to leave a residue free finish.

For professional and industrial use only.

Truck-mount units - Mix 650ml by volume of Heat Wave powder in 20 litres of hot water to make metering concentrate.

Set flow meter at 2 to 4 GPH. 4 kilos of Heat Wave powder makes approx. 120 litres of metering concentrate.

Portable extraction machines - Mix 15ml (1 measure scoop) of Heat Wave powder per 10 litres of hot water in the extraction machine solution tank. 4 kilos of Heat Wave powder makes approx. 2500 litres of cleaning solution.

Always pretest carpet for colour fastness with ready-to-use solution before proceeding. Pretreat heavily soiled areas with S888 Ultraprep TLC or S789 Power Burst according to label directions, then follow up with normal extraction cleaning procedure.

- Super-strength high heat carpet detergent for truck mounted and portable extractors.
- Performs at high temperatures while maintaining stability and 100% clarity.
- Heat Wave's ingredients will not separate under high heat, reducing residual deposits and clogged wands.
- Light red powder with tropical lemon fragrance.

pH (Diluted): 9.5

DANGER. Causes severe skin burns and eye damage. May be corrosive to metals.

Keep out of reach of children. Wear protective gloves / protective clothing / eye protection / face protection. IF IN EYES: Rinse cautiously with water for several minutes.

Remove contact lenses, if present and easy to do. Continue rinsing.

IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water / shower. Immediately call a POISON CENTER / doctor.

Please consult the Safety Data Sheet before using this product.

This product is intended for professional use only. The information given is intended to be of assistance to users but is without guarantee. Variations can occur in application and users are advised to conduct their own tests. Suggestions for use neither give nor imply any guarantee as to the intended use.

